

I/O Addresses

A 32-byte block of I/O addresses is required to communicate with the processor. Be careful not to use an address of another controller in the computer. If two controllers share I/O addresses, they will not operate correctly. Choose from the following I/O addresses:

I/O Address Blocks		
Address	Address	Address
0240 to 25Fh	02C0 to 2DFh	0380 to 38Fh
1A20 to 1A3Fh	0300 to 31Fh	0A20 to A3Fh (default)
0280 to 29Fh	0340 to 35F	