


LS-120 Drive Jumper Settings and Locations

Diskette Drive: 120 MB Model: LS-120

LS-120 MB Diskette Drive
Assembly Number 184932



A Configuration | IA | 1DRV | 2CSL | 2MST

Cable-Select | | | |

Device 0 (master) | | | |

Device 1 (slave) | | | |

Jumper IA is for factory use only.
Jumper 1DRV does not need to
be used.

B Configuration | MD0 | CS | SZ | MA

Cable-Select | | | |

Device 0 (master) | | | |

Device 1 (slave) | | | |

Jumper MD0 is for factory use only.



Jumper NOT Installed

Jumper Installed