

CD Storage System

Boards	Spare Part
SCSI Interface	306258-001
CD, SCSI Express Software (card)	306291-001

CD-ROM Drives	Spare Part
CD-ROM, 12X, SCSI	306259-001

Miscellaneous	Spare Part
Switch, SCSI Selector w/cable	306274-001
SCSI Terminator	306278-001

Cables	Spare Part
Cable Kit, Misc Power, w/ LEDs	306272-001
Cable Kit, Misc SCSI Signal	306273-001
AC Adapter 6'	129827-001
AC Adapter 12'	187335-001
External, 3'	146776-001
External, 6', ProLiant	146745-001
External, W/N-SCSI, 12'	189636-001
External, W/N-SCSI, 6'	189636-001

Power Supply	Spare Part
Power Supply	306257-001