

SLT/286

System Boards	Assembly	Spare Part
80286 System Board	DISCONTINUED	110355-001
80286 System Board	DISCONTINUED	110355-001

* Comes with Memory Module (Assembly 001163) mounted on system board.

System Board Jumper Settings (System Board 000851 and 001160)

J1 Settings *	Function
1 to 2 **	8-MHz 80287
2 to 3	12-MHz 80C287

* Jumpers E2, E3, and E4 reserved. These jumpers *must be installed* for proper board operation.

** Default.

Memory Boards	Assembly	Spare Part
1 MB Memory Board	DISCONTINUED	110357-001
1 MB Memory Board	DISCONTINUED	110357-001
4 MB Memory Board	DISCONTINUED	110863-001

Video Boards *	Assembly	Spare Part
Advanced Graphics 1024 Board **	109958	114201-001
Advanced Graphics Memory Board	109959	114202-001

* Used in Desktop Expansion Base only.

** See Volume 2 Appendix, Multiproduct Boards, for settings.

Hard Drives

Size	Type	Inter-leave	Integrated	Min ROM	Spare Part
20 MB	2	1:1	Y	F.2	Not Available
20 MB	2	3:1	Y	F.2	Not Available
40 MB	22	1:1	Y	F.2	Not Available
120 MB	50	1:1	Y	K.1	118360-001 ¹ DISCONTINUED

¹ Except Europe.

² Europe only.

Tape Drives *	Spare Part	Tape Cartridge	Spare Part
40/60 MB (1/2 Height)**	112524-001	40 MB (DC2000)	108142-001
		60 MB (DC2060)	122086-001
60 MB (1/3Height)**	131338-001	60 MB (DC2060)	122086-001

* Used in External Storage Module only.

** With compression.

Diskette Drives	Spare Part
1.2 MB *	112566-001
360 KB *	112567-001
1.44 MB	110356-001

* Used in External Storage Module only.

SLT/286

Miscellaneous Internal	Assembly	Spare Part
2400 Baud Internal Modem	DISCONTINUED	110352-001
Serial Interface	000854	110360-001
Display Panel		110451-001
Backlight Inverter	000908	110452-001
LED Indicator	DISCONTINUED	110453-001
Extender Connector *	000872	110600-001
CPU Connector *	001340	110601-001
Enhanced 2400 Baud Internal Modem **	DISCONTINUED	118413-001

* Used in Desktop Expansion Base only.

** Refer to Page E-6 for country-specific 2400 Baud Internal Modem Assembly/Spare Part information.

Miscellaneous External	Option Part	Spare Part
External Numeric Keypad	110052-001 (English) 110052-003 (French)	110454-001
Desktop Expansion Base	110059-001	Not available
Battery Pack	DISCONTINUED	110351-001
CD-ROM Adapter	DISCONTINUED	110875-001
Automobile Adapter	110288-001	110708-001**
External Battery Charger	110700-001	110706-001
External Storage Module	110281-001 (110V) 110281-002 (220V)	Not available
External Storage Module *	117079-001 (110V) 117079-002 (220V)	Not available
AC Adapter	110888-001	110353-001
AC Adapter	DISCONTINUED	118460-001

* Requires External Storage Module Adapter Cable (DISCONTINUED-Spare Part 119198-001) or Adapter Plug (DISCONTINUED -Spare Part 121986-001).

** Discontinued (unavailable)

Cables	Used With	Spare Part
Mass Storage Power Cable	All Hard Drives	110007-001
Hard Drive Signal Cable	All Hard Drives	110008-001
Diskette Power/Signal Cable	Internal Diskette	110005-001
Signal Cable	External Storage Module	110268-001
Power Cable	External Storage Module	110270-001
Ground Cable	Display	110503-001
Power Cord	AC Adapter	110543-001
Telephone Cable *	Modem	112666-001
Adapter Cable	DISCONTINUED	119198-001
Cable Kit (4 Cables)	All Drives	110551-001
Cable Kit (2 Cables)	Drive Signal and Power	110553-001
Egress Power Cable	DISCONTINUED	

* U.S. and Canada only.

External Storage Module Jumper Settings

Jumper	Function
Diskette	Enables diskette drive
Tape	Enables tape drive

Processor/Coprocessor Locations

Processor (80C286-12)	Coprocessor (80287-8 or 80C287-12)
U31	U45

SLT/286

System ROM Locations

U56 ODD	U57 EVEN
---------	----------

System ROM Revision (Spare Part 110542-001) DISCONTINUED

Revision	Number on ODD ROM	Number on EVEN ROM
F.2	110091-002	110092-002
F.5	110091-003	110092-003
G.2	110091-005	110092-005
H.1	110091-006	110092-006
H.2	110091-007	110092-007
H.3	110091-008	110092-008
H.4	110091-009	110092-009
H.5	110091-010	110092-010
H.6	110091-011	110092-011
H.7	110091-012	110092-012
J.1	110091-013	110092-013
J.2	110091-014	110092-014
K.1	110091-015	110092-015

Power Supply/Battery	Spare Part
AC Adapter Power Supply	110353-001
DC Internal Power Supply	110361-001
Desktop Expansion Base Power Supply	110599-001
External Storage Module Power Supply	110448-001
Battery RTC XL	149344-001

SLT/286

MEMORY UPGRADE CHART

