

Compaq Processor Upgrades

Deskpro				
Model	Socket Pins	Configuration Code	Processor Board	Processor Chip
4/25	168	HAJ	no	50 MHz DX
466, 450	238	HKR, HKS, HKQ, HKT, HKU, HKV, HLE, HLF	no	100 MHz DX4
5133, 5120, 5100, 590 575	320	HMW, HMX, HKW, HSE, HMY, HGL, HNX, HSZ, HSY, HTA, HSF, HSG, GSG, HSJ, GSJ, GKW, HSX, GSX, HSI, GSI, HSY, GSY, HTL, GTL, HSH, GSH	no	90 MHz Pentium (DP575 only)

Deskpro i				
Model	Socket Pins	Configuration Code	Processor Board	Processor Chip
386	169	HEA, HCP, HCQ, HEB	no	66 MHz DX2
486	238	HFW, HFY, HFZ	no	66 MHz DX2
486	169	HCR, HEF, HCS, HEG, HCT, HEH, HEC, HED, HEE	no	66 MHz DX2

Deskpro L				
Model	Socket Pins	Configuration Code	Processor Board	Processor Chip
386/33L		HAS	to 486/33	no
486/33L	168	HAM	no	66 MHz DX
486/50L	168	HBA	no	no

Deskpro M				
Model	Socket Pins	Configuration Code	Processor Board	Processor Chip
386	386	HBR (25MHz) HBV (33MHz)	to Pentium 60	no
4/33M	168	HBN	to Pentium 60	66 MHz DX2
4/50M	168	HBP	to Pentium 60	no
4/66M	238	HCJ	to Pentium 60	no
486s/16 486s/25 ¹	169	HLB (16MHz) HBM (25MHz)	to Pentium 60	33 MHz DX 50 MHz DX2
486s/33M	169	HGF	to Pentium 60	33 MHz DX 66 MHz DX2
5/60M	273	HFA	no	no
5/66M	273	HFB	no	no

¹ Some versions support selectable processor bus speed while others do not. When upgrading a Deskpro 486/16M without selectable processor bus speed, be aware that a 33 MHz 486DX upgrade processor operates at 16 MHz; the 50 MHz DX2 and OverDrive processors will operate at 32 MHz; and the 75 MHz DX4 and OverDrive processors operates at 48 MHz.

Compaq Processor Upgrades

Deskpro XE				
Model	Socket Pins	Configuration Code	Processor Board	Processor Chip
486	238	HGW, HGX, HGY, HKH	no	66 MHz DX2
560	273	HFC	no	no

Deskpro XL				
Model	Socket Pins	Configuration Code	Processor Board	Processor Chip
450	238	HHL	to 133 MHz Pentium	no
466	238	HHM	to 133 MHz Pentium	no
560, 566	273	60 MHz HHN 66 MHz HHP	to 133 MHz Pentium	no
575, 590 5100	320	HPR (100 MHz) HHR (90 MHz) HPQ (75 MHz)	to 133 MHz Pentium	125 MHz Pentium
5120	320	HRC (120 MHz)	to 133 MHz Pentium	no
5133	320	HSN	no	no

Presario				
Model	Socket Pins	Configuration Code	Processor Board	Processor Chip
425, 433, 520, 524, 526, 528, 625, 633, 660	169	HFG, HJA, HLM, HQS, HQJ, HHY, HGU, HGT, HJE	no	66 MHz DX2
466	169	HJA	no	66 MHz DX2
510	169	HLL	no	50 MHz DX2 66 MHz DX2
650	169	HKN	no	66 MHz DX2
720, 724, 744, 920, 924	238	HLV, HLW, HQB, HLU, HMB, HMC, HLY, HLZ	no	100 MHz DX4
762, 962	273	HPS, HPT	no	no
772, 774, 972, 974, 978, 982, 992	320	HPU, HPW, HPX, HPY, HQZ	no	to 100 MHz Pentium
833, 850, 860	238	HHD, HHE, HKL	no	66 MHz DX2
866	238	HHF	no	no
940, 942, 944, 948, 954	238	HQC, HQD, HQF, HQG	no	100 MHz DX4

Compaq Processor Upgrades

ProLinea				
Model	Socket Pins	Configuration Code	Processor Board	Processor Chip
3/25s, 3/25zs		HCU, HCV	no	N/A
4/25s	169	HEP, HEQ	no	66 MHz DX2 50 MHz DX2
4/25s	169	HDU	no	50 MHz DX2
4/33	168	HCW	no	66 MHz DX2
4/33, 4/33s	169	HER, HEU, HES, HGN, HGP	no	66 MHz DX2
4/50	169	HET	no	66 MHz DX2
4/50	168	HDV	no	no
4/66	169	HEV, HEW	no	N/A
466, 450	238	HKZ, GKZ, HLB, GLB, HLH, GLH, HKY, GKY, HLA, GLA	no	100 MHz DX4
5133, 5120, 5100, 590, 575	320	HMZ, GMZ, HNA, GNA, HNB, GNB, HLD, GLD, HLK, GLK, HNY, GNY, HSD, GSD, HTX, GTX, HTA, GTA, HTN, GTN, HTO, GTO, HTP, GTP, HSF, GSF, HSU, GSU, HTQ, GTQ, HTR, GTR, HSK, GSK	no	90 MHz Pentium (PL575 only)
MT	238	HHA, HHB, HHC	no	66 MHz DX2
Net/1	169	HJB	no	66 MHz DX2

ProLinea (Enhanced)				
Model	Socket Pins	Configuration Code	Processor Board	Processor Chip
4/33s	238	HKA	no	66 MHz DX2
4/50	238	HKC, HND	no	66 MHz DX2
4/50s	238	HKB	no	66 MHz DX2
4/66	238	HKD, HNE	no	N/A
4/100	238	HKE	no	N/A