

Configuration Codes: Storage System/F, /U, /Fibre Channel

MODEL	CONFIGURATION CODE	INDEX
ProLiant Storage System F1 Tower SB	BHM1	272901-002
ProLiant Storage System F2 Tower DB	BHM2	272901-002
ProLiant Storage System F1 Rack SB	BHN1	272801-002
ProLiant Storage System F2 Rack DB	BHN2	272801-002
Kit, Conversion SB-F1	BQK1	272826-001
Kit, Conversion DB-F2	BQK2	272830-001
Kit, Conversion SB-U1	BQK3	304115-B21
Kit, Conversion DB-U2	BQK4	304116-B21
ProLiant Storage System UE Rack	BQK5	348700-001
ProLiant Storage System UE Tower	BQK6	348710-002
ProLiant Storage System U1 Tower SB	BSN1	304110-B21
ProLiant Storage System U2 Tower DB	BSN2	304110-B22
ProLiant Storage System U1 Rack SB	BSP1	304100-B21
ProLiant Storage System U2 Rack DB	BSP2	304100-B22
Kit, Opt, Storage Array (Fibre Channel)	BYY1	296324-B21
ProLiant Storage Upgrade	BYY1	296324-B21
Fibre Storage HUB7	BZX1	234453-001
Fibre Channel Array Rack DB	HUQ1	223101-002
Fibre Channel System Rack	HUQ1	223100-001
Fibre Channel Array Tower DB	HUS1	223101-002
Fibre Channel System Tower	HUS1	241300-001