

Deskpro Workstation 300

Processor/System Boards	Assembly	Spare Part
400 Electra	010821-101	221183-001

Configuration Code	Assembly	System Bd Spare Part
JSSZ	010821-001	221183-001

Microprocessors	Assembly	Spare Part
1.4 GHZ, FCPGA, B-1	174531-002	221184-001
1.5 GHZ, FCPGA, B-1	174531-003	221185-001

Memory	Assembly	Spare Part
64 MB, PC800, RDRAM	402831-862	157108-001
128 MB, PC800, RDRAM	402833-862	157112-001
256 MB, 45ns, RDRAM	402835-862	161454-001
Memory Board, CRIMM	010566-001	158265-001

Miscellaneous	Assembly	Spare Part
Baffle, Heatsink	194501-001	224205-001
Bezel, Front	194713-002	221187-001
Fan, 92MM	166809-002	158275-001
Heatsink	195350-001	225354-001
Keyboard, Easy Access- US	122659-006	123130-001
Mouse, 3 Button Opal	269210-006	327716-001
Mouse Scroll	334684-006	334689-001
Plastic Kit Miscellaneous	166776-001	166878-001
Plastic Kit Miscellaneous	166778-001	400549-001
Speaker 40MMX X 70MM	174922-001	180809-001

Controller Boards	Assembly	Spare Part
NIC, 10/100, IPSEC	213464-001	215774-001
NIC, 10/100 PCI	108897-001	116188-001
NIC, 10/100 PCI AOL	402355-001	118042-001
Ultra3 SCSI Controller, PCI	157342-001	158364-001

Graphic Boards	Assembly	Spare Part
ELSA GLoria II 3D, 64 MB	174565-001	174641-001
ELSA Synergy II	103384-003	146140-001
Matrox Millennium G450, 32 MB (AGP)	202901-001	203626-001
NVIDIA Synergy III, 32 MB, Quadro 2 MXR	221411-001	221492-001
NVIDIA TNT2 16M SDRAM	175779-001	179997-001

CD-ROM/DVD-ROM Drives	Assembly	Spare Part
CD-ROM, 32X, Read/Write	165599-001	101916-001
CD-ROM, 48X	176135-E73	187263-001
DVD-ROM, 10X, Opal	177722-F70	215422-001

Deskpro Workstation 300

Hard Drives	Assembly	Spare Part
9 GB Ultra3, SCSI	153334-001	160062-001
18 GB Ultra3, SCSI	153335-001	160063-001
18.2 GB Ultra3, SCSI, 1 inch	180334-001	194585-001
20.0 GB (7200 rpm)	167965-002	180475-001
30 GB (7200 rpm)	189099-001	180477-001
36 GB Ultra3, SCSI	155694-001	167926-001
36.2 GB Ultra3, SCSI, 1inch	180337-001	192197-001

Diskette Drives	Assembly	Spare Part
1.44 MB	388617-702	158266-001
Diskette Drive Adapter, M3	179026-008	180808-001
SuperDK 2X-Opal	179204-001	103421-001
Zip Drive, 250MB, 1 inch, Opal, I/O	325024-701	125776-001


Cables	Assembly	Spare Part
Audio CD Cable	387527-001	149806-001
Cable, Diskette DTA, 18.0 inch	143218-003	221186-001
Cable, Dual Connection, IDE, UATA, 18 inch	108950-015	225881-001
Cable, Hard Drive	108950-020	170255-001
Cable, SCSI, LVD, Twisted Pair	155825-001	158277-001
Kit, Miscellaneous Cable	108950-007	166879-002

Battery/Power Supply	Assembly	Spare Part
Battery, 770 Disc, Lithium/MN02, 3V	166899-001	153099-001
Power Supply, 265W, 3.3, Dual Aux	221253-001	224884-001
Power Supply, 265W, 3.3V	195196-001	203430-001

Deskpro Workstation 300


Memory Upgrade Chart

SYSTEM BOARD
221183-001



A MAXIMUM OF 1GB TOTAL MEMORY

NOTE: Memory must be installed in like pairs.
Option kits contain one memory module



64-MB Memory Kit (RDRAM RIMM, 800 MHz)	OPTION PN 157341-B21
128-MB Memory Kit (RDRAM RIMM, 800 MHz)	OPTION PN 157338-B21
256-MB Memory Kit (RDRAM RIMM, 800 MHz)	OPTION PN 157335-B21