

DLT Library II

Controller Boards	Spare Part
Controller	340551-001
SCSI Interface	340552-001

Tape Drives/Cartridges	Assembly	Spare Part
7000 DLT		295648-001
Magazine		295171-001
Cleaning Cartridge, DLT	199680-001	199705-001

Miscellaneous	Spare Part
Display Panel	295172-001
Fan	295174-001
SCSI Terminator	295282-001
Rack Mount Kit	295377-001

Cables	Spare Part
24V DC Power	295204-001
12V AC Power	295205-001
Control Panel Transmitter	295206-001
Door Interlock	295207-001
Magazine Interlock	295208-001
Vertical Lift, Ribbon	295209-001
Translator, Ribbon	295210-001
Auto Changer Control	295211-001
Drive Interface Extend	295215-001
Left Drive Interface	295217-001
Right Drive Interface	295218-001
Bezel Sensor	295219-001
Barcode	295220-001
Front Panel, Ribbon	295272-001
SCSI, 68-Pin	340561-001
Drive Power	340550-001
UART	340553-001

Power Supply	Spare Part
Power Supply, 12V/200W	295184-001
Power Supply, 24V	295185-001