

Handheld Options

Memory	Option Part	Assembly	Spare Part	System
Memory Card, 20 MB, CompactFlash	104703-001		110784-001	Aero 1500
16 MB RAM/ROM, Pocket PC	175593-001		177669-001	Aero 1500
Upgrade – English	175593-051		177669-051	
	175593-041		177669-041	
	175593-061		177669-061	
	175593-071		177669-071	
Memory Card, 32 MB, CompactFlash	104703-004	127376-004	176324-001	Aero 1500
Memory Card, 64 MB, CompactFlash	104703-003	127376-003	127473-001	Aero 1500
Memory Card, 40 MB, CompactFlash	104703-002		110592-001	Aero 1500

Miscellaneous	Option Part	Assembly	Spare Part	System
Adapter, Auto Power	104929-B21		109966-001	Aero 1500
Deluxe Case, Leather	136177-B21		146653-001	Aero 1500
Executive Case, Portfolio	402148-B21		115619-001	Aero 1500
Mouse, Scrolling (Intellimouse)	294306-B21	317857-001	317863-001	All except Handheld PCs
Security Lock		294316-B21	294359-001	All (cradle required w/C-Series)
Sport Pouch	157941-B21		160208-001	Aero 1500

Cables	Option Part	Spare Part	System
Autosync Cable, Serial	402146-B21	103713-001	Aero 1500
Serial Adapter Cable	140143-B21	148920-001	Aero 1500

Modems	Option Part	Spare Part	System
56K, CompactFlash	148908-001	122717-001	Aero 1500
	148908-031	122717-002	
	148908-111	122717-002	
	148908-A21	122717-002	
	148908-B31	122717-002	