

Presario 1200/1600

System/Processor Boards	Assembly	Spare Part	System
Processor Board w/o Processor		331009-001	1640, 50, 55
Processor Board w/o Processor		330982-001	1624, 25, 26, 35, 36, 40
Processor Board w/ 32 MB		356877-001	1234, 35, 36, 37, 38, 40, 42, 50, 52
Processor Board w/ 32 MB		330938-001	1230
Processor Board w/ 32 MB SDRAM		142646-001	1272, 73, 74, 75
System Board 586/200GXM, Processor		203716-001	1220, 1220ES
System Board 586/180GXM, Processor		203718-001	1215
System Board, I/O		400440-001	1670
System Board, I/O w/ 32 MB SDRAM		102246-001	1255, 60, 66, 67
System Board, I/O w/ 64 MB SDRAM	50M101Z01-S0	159483-001	1600
System Board, I/O w/ 512K Cache		144018-001	1683, 85, 87, 88, 90
System Board, I/O w/ 512K Cache w/ 32 MB RAM		158793-001	1246, 47
System Board, I/O w/ 512K Cache w/ 64 MB RAM		158794-001	1246, 77, 78
System Board w/ 256K Cache USB		332246-001	1611, 21, 22, 30, 81
System Board w/ 32 MB SDRAM w/o FMDM		102247-001	1255, 60, 66, 67
System Board w/ 64 MB RAM		387539-001	1660
System Board w/ Cache, w/o Processor		293785-001	1207, 10
System Board w/o Cache, w/o Processor		293786-001	1610, 11, 15, 20, 21, 22, 30, 81
System Board, w/o Processor		203731-001	1220
System Board, w/o Processor		327715-001	1215
System Board, w/o Processor		298638-001	1610, 11, 15, 20, 21, 22, 30, 81

Configuration Code	System Board Spare Part	Model
BQB3	293786-001	1615
BQB5	293786-001	1615
BQB6	293786-001	1610
BQC2	293786-001	1620
BQC4	293786-001	1682
BQH2	293785-001	1210
BQH3	293785-001	1207
BQH4	293785-001	1207
BQH5	293785-001	1207
BVL2	203716-001	1220
BVL4	203716-001	1220

Continued

Presario 1200/1600

Configuration Code	System Board Spare Part	Model
BVM3	298638-001	1621
BVM4	332246-001	1611
BVMJ	298638-001	1621
BVP2	332246-001	1681
BVP3	332246-001	1681
BVP4	298638-001	1622
BVR3	332246-001	1630
BXN2	203731-001	1215
BY44	330938-001	1230
BY53	330982-001	1625
BY54	330982-001	1635
BY56	330982-001	1624
BY66	331009-001	1650
BY67	331009-001	1655
BY86	356877-001	1235
BY87	356877-001	1238
BY88	356877-001	1237
BY8B	356877-001	1235
BY8H	356877-001	1234
BY8K	356877-001	1236
BYG2	356877-001	1240
BYG3	356877-001	1240
BYG4	356877-001	1242
BYG5	356877-001	1240
BZP3	330982-001	1640
CF42	356877-001	1252
CF43	356877-001	1250
CFK2	102246-001	1255
CFK3	102246-001	1255
CFK4	102246-001	1255
CFK5	102246-001	1260
CFK6	102246-001	1255
CFK7	102246-001	1260
CFK8	102246-001	1266
CFKB	102246-001	1267
CFKC	102246-001	1260
CFKD	102246-001	1260
CGX3	400440-001	1670
CLR3	142646-001	1275
CLR4	142646-001	1273
CLR5	142646-001	1272
CLR7	142646-001	1275
CLR8	142646-001	1274
CLRG	142646-001	1275
CLS3	144018-001	1688
CLS5	144018-001	1685
CLS8	144018-001	1688
CLS9	144018-001	1685

Continued

Presario 1200/1600

Configuration Code	System Board Spare Part	Model
CLSB	144018-001	1690
CLSC	144018-001	1687
CLSF	144018-001	1690
CTS1	158793-001	1246
CTS3	158794-001	1277
CTS6	158793-001	1246
CTS7	158794-001	1278
CTS9	158793-001	1247
CTSD	158794-001	1277
DCJ1	159483-001	1600
DCJ2	159483-001	1600
DCJ3	159483-001	1600
DCJ4	159483-001	1600
DCJ6	159483-001	1600
DCJ7	159483-001	1600
DCJ8	159483-001	1600
DCJ9	159483-001	1600
DCJB	159483-001	1600
DCJC	159483-001	1600

Microprocessors	Assembly	Spare Part	System
233 GXM Processor		330937-001	1230
466 MHz, 128K Cache	50M101Z44-S0	174040-001	1600
500 MHz, 128K Cache, 2V	50M101Z02-S0	159484-001	1600
586/200 GXM w/ Processor Board		203734-001	1220, 1220ES
686/150 w/ Heat Sink		293828-001	1207, 10, 1620
686/180 GXM		203718-001	1215
686/200 MMX Processor		203734-001	1611
686/150 MMX w/ Heat Sink		293829-001	1610, 15
686/166 MMX w/ Heat Sink		293717-001	1620, 82
686/200 MMX w/ Heat Sink		293718-001	1620, 82
686/233 MMX Processor		298609-001	1621, 22, 24, 35, 36, 81
686/233 MMX Processor		293849-001	1622
686/266 MMX Processor		332216-001	1234, 35, 36, 37, 38; 1625, 26, 40, 81
DII/300 Processor, 128K		400782-001	1660
K6/300 Processor		356886-001	1250, 52
K6II/333 Processor		400442-001	1255, 60, 66, 67; 1670
K6II/350 Processor, AMD, 2.2V		122698-001	1683
K6II/366 Processor		142647-001	1272, 73, 74, 75
K6II/380 Processor, AMD, 2.2V		123923-001	1685, 87, 88
K6II/400 Processor, AMD, 2.2V		134079-001	1246, 47; 1685, 88, 90
K611/433 Processor, AMD		158851-001	1277, 1278
P/266 MAX Processor		356885-001	1240, 42
PII/266 Processor		330983-001	1640, 50, 55
PIII/500 MHz, 256K Cache	50M101Z45-S0	174041-001	1600

Presario 1200/1600

Memory Modules/Boards	Assembly	Spare Part	System
16 MB Memory, SODIMM		293726-001	All
32 MB Memory, SODIMM		293727-001	All
32 MB Memory, SODIMM, PC100	50M101D41-S0	122699-001	1683, 85, 87
64 MB Memory, SODIMM		332208-001	All
64 MB Memory, SODIMM, PC100	50M101D42-S0	122700-001	1685, 87, 88, 90
128 MB Memory, SODIMM		388646-001	1660, 70

Hard Drives	Assembly	Spare Part	System
1.4 GB, IDE		293779-001	1207, 10
1.4 GB, IDE		203740-001	1215
1.6 GB, IDE		293794-001	1610, 15
2.1 GB, IDE		298764-001	1220
2.1 GB, IDE		332223-001	1611, 20, 21
2.1 GB, IDE		330933-001	1230
3.2 GB		142309-001	1683
3.2 GB, IDE		298502-001	1622, 1681
3.2 GB, IDE		330968-001	1230; 1624, 25, 34, 35, 36, 40, 42
4.0 GB, IDE		330969-001	1260, 66, 67; 1626, 35, 36, 37, 38, 40, 50, 52, 55, 60, 70
4.3 GB, IDE		144410-001	1246, 47, 72, 74, 75, 77, 78; 1685, 87, 88
4.8 GB, IDE		142310-001	1246, 77, 78, 79; 1685, 88
6.0 GB	50M101Z23-S0	170087-001	1600
6.4 GB, IDE		347548-001	1250, 60, 66
6.4 GB, IDE		142311-001	1685, 90
6.4 GB, IDE		142651-001	1273
12.0 GB	50M101Z24-S0	170086-001	1600

Diskette Drives	Assembly	Spare Part	System
1.44 MB		293784-001	All
1.44 MB		331165-001	1640, 50, 55
1.44 MB		332233-001	1624, 25, 26, 35, 36, 40
1.44 MB		330947-001	1230, 34, 35, 36, 37, 38, 40, 42, 50, 52, 55, 60, 66, 67; 1660, 70
1.44 MB		141847-001	1246, 47, 72, 73, 74, 75, 77, 78; 1683, 85, 87, 88, 90
1.44 MB	50M101Z14-S0	159496-001	1600

Presario 1200/1600

CD-ROM	Assembly	Spare Part	System
14X Max		203741-001	1215
14X Max CD-ROM (Black)		297657-001	1207, 10; 1610
20X Max CD-ROM		203736-001	1220
20X Max CD-ROM		332225-001	1611, 20, 21, 22, 30, 81
24X CD-ROM		331015-001	1624, 25, 26, 35, 36, 40
24X CD-ROM		330967-001	1640, 50, 55
24X CD-ROM		330934-001	1230, 34, 35, 36, 37, 38, 40, 42, 50, 52; 1670
24X CD-ROM		386891-001	1255, 60, 66, 67
24X CD-ROM, 1000	50M101Z05-S0	159487-001	1600
24X Max CD-ROM, IDE, 2C		142307-001	1246, 47, 77, 78; 1683, 85, 88, 90
24X CD-ROM, 2C		142650-001	1272, 73, 74, 75
DVD		387543-001	1660
DVD, 4X		142308-001	1685, 87, 90
DVD, 6X, 3C	50M101Z06-S0	159488-001	1600

Cables	Assembly	Spare Part	System
Flat Panel, Cable to Interface Board		152186-001	1246, 77, 78, 79
Misc. Cable Kit		293759-001	All
Misc. Cable Kit		203714-001	1215, 20, 20ES
Misc. Cable Kit		332234-001	1611, 21, 22, 24, 25, 26, 30, 35, 36, 40, 50, 55, 81
Misc. Cable Kit		293759-001	All
Misc. Cable Kit		330946-001	1230, 34, 35, 36, 37, 38, 40, 42, 46, 47, 50, 52, 55, 60, 66, 67, 72, 73, 74, 75, 77, 78, 79; 1660, 70, 83, 85, 87, 88, 90
Misc. Cable Kit	50M101Z15-S0	159497-001	1600

Miscellaneous Internal	Assembly	Spare Part	System
Audio Board w/ Jacks		293882-001	1610, 11, 15, 20, 21, 22, 24, 25, 26, 30, 35, 36, 40, 81
Audio Board w/ Jacks – Lite		293756-001	1207, 10
Audio Board w/ Jacks		331010-001	1640, 50, 55
Fan		346863-001	1234, 35, 36, 37, 38, 40, 42, 50, 52, 55, 60, 66, 67
Fan		293747-001	All
Fan		332228-001	1611, 21, 22, 24, 25, 26, 30, 35, 36, 40, 50, 55, 81
Fan		293747-001	1622
Fan		102269-001	1660
Fan		400444-001	1670, 83, 85, 87, 88, 90
Fan		102249-001	1272, 73, 74, 75
Fan	50M101Z18-S0	159500-001	1600

Continued

Presario 1200/1600

Miscellaneous Internal	Assembly	Spare Part	System
Fan, 5500 rpm		158801-001	1246, 47, 77, 78, 79
Fan, 7000 rpm		158800-001	1246, 47, 77, 78, 79
Heat Spreader		122702-001	1683, 85, 87, 88, 90
Heat Spreader, 2000		158802-001	1246, 47, 77, 78, 79
Head Spreader FCPGA, 1000	50M101Z46-S0	174042-001	1600
Head Spreader, 1000	50M101Z19-S0	159501-001	1600
LCD Interface Board w/ Header		293746-001	All
LCD Interface Board TFT		331016-001	1626, 35, 36, 40
LCD Interface Board TFT		293156-001	1640, 50, 55
Voltage Converter Board		293748-001	All
Voltage Converter Board		331019-001	1640, 50, 55
Voltage Converter Board		330962-001	1230
Voltage Converter Board, 3C	50M101F43-S0	352891-001	1234, 35, 36, 37, 38, 40, 42, 46, 47, 50, 52, 55, 60, 66, 67, 1272, 73, 74, 75, 77, 78, 79; 1600, 60, 70, 83, 85, 87, 88, 90

Miscellaneous External	Assembly	Spare Part	System
AC Adapter	50M101P23-S0	298239-001	All (new smaller size)
AC Adapter		293787-001	All
AC Adapter, APD	50M101X50-S0	164854-001	1600
Base Enclosure		387542-001	1660
Base Enclosure		400441-001	1670
Base Enclosure	50M101D97-S0	141845-001	1683, 85, 87, 88, 90
Base Enclosure	50M101Z09-S0	159491-001	1600
Base Enclosure		158798-001	1246, 47, 77, 78
Button Board Cover, 1000	50M101Z11-S0	159493-001	1600
CPU Cover, Upper		203739-001	1215, 1220
CPU Cover, Upper, 1000	50M101Z10-S0	159492-001	1600
CPU Cover w/ Cable & Power Switch		293739-001	All
CPU Cover w/ Power Switch		330963-001	1255, 60, 66, 67; 1660
CPU Cover w/ Power Switch		400443-001	1670
CPU Cover w/ Power Switch		141846-001	1683, 85, 87, 88, 90
Hardware Kit, Misc.		346853-001	1234, 35, 36, 37, 38, 40, 46, 47, 50, 52, 55, 60, 66, 67, 1272, 73, 74, 75, 77, 78, 79; 1660, 83, 85, 87, 88, 90

Continued

Presario 1200/1600

Miscellaneous			
External	Assembly	Spare Part	System
Hardware Kit, Misc.	50M101Z17-S0	159499-001	1600
Keyboard, US		293776-001	1210, 1620
Keyboard, US		330956-001	1230, 34, 35, 36, 37, 38, 40, 50, 52; 1670
Keyboard, US		330981-001	1624, 25, 26, 40, 50, 55
Keyboard		102250-001	1260
Keyboard		102270-001	1660
Keyboard		141706-XXX	1246, 47, 72, 73, 74, 75, 77, 78, 79; 1685, 87, 88, 90
Keyboard	50M101Z07-S0	170090-001	1600
LCD Board w/ Internet Switch	50M101Z13-S0	159495-001	1600
LCD Indicator Module	50M101Z16-S0	138187-001	1600
Modem, 33.6+Data/Fax	298958-002	298974-002	1215, 20, 07
Modem, 33.6 Voice/Data/Fax	298958-001	298973-001	1615, 21, 30, 61
Modem, 56.0 Voice/Data/Fax	292306-001	292312-001	1611
Modem, 56.6+Data/Fax	292306-002	292311-001	1220, 10, 07
Modem, 56K Data/Fax		138657-001	1215, 20, 30; 1621, 22, 24, 25, 26, 36, 40, 50, 55, 81
Modem, 56K Data/Fax	292306-001	138610-001	1230, 34, 40, 42, 55, 60; 1635, 50, 60
Modem, 56K Data/Fax w/o SRAM		138659-001	1235, 36, 37, 38, 40, 50, 52, 55, 60, 66, 67, 72, 73, 74, 75; 1660
Modem, K-56K Data/Fax w/o SRAM	50M101D48-S0	400445-001	1246, 47, 77, 78; 1685, 87, 88, 90
Modem, K-56K Data/Fax w/o SRAM – International	50M102D02-S0	143848-001	1683, 85, 90
Modem, K-56K Mini 3 – Australia	50M101Z43-S0	159502-011	1600
Modem, K-56K Mini 3 – International	50M101Z20-S0	159502-002	1600
Modem, K-56K Mini 3 – United States	50M101Z40-S0	159502-001	1600
Palm Rest w/ Board & Cables		293716-001	All
Palm Rest		203737-001	1215, 1220
Palm Rest		332226-001	1611, 21, 22, 24, 25, 26, 30, 35, 36, 40, 50, 55, 81
Palm Rest		330965-001	1230
Palm Rest		352888-001	1234, 35, 36, 37, 38, 40, 42, 50, 52
Palm Rest w/ Touchpad/Button Board		387540-001	1255, 60, 66, 67; 1660, 70

Continued

Presario 1200/1600

Miscellaneous External	Assembly	Spare Part	System
Palm Rest w/ Touchpad/Button Board		142653-001	1272, 73, 74, 75; 1683, 85, 87
Palm Rest w/ Touchpad/Button Board		142654-001	1688, 90
Palm Rest w/ Touchpad/Button Board 1000	50M101Z08-S0	159490-001	1600
Palm Rest w/ Touchpad/Button Board w/o Soft Paint		161416-001	1278
Plastic Kit, Miscellaneous	50M101Z16-S0	159498-001	1600
Plastic Kit, Miscellaneous		142657-001	1246, 47, 77, 78
Port Replicator		293857-001	All 1600 series except 1600i, 1600s, 1670, 72, 75, 83, 85, 87, 88, 90, 92, 93, 94
Port Replicator		102270-001	1270, 1600i, 1600s, 1670, 72, 75, 83, 85, 87, 88, 90, 92, 93, 94
Port Replicator	50M101Z49-S0	175310-001	1600
Speakers, Left and Right		293757-001	1215, 1220
Speakers, Left and Right		293782-001	All ex 1207, 10
Speakers, Lite		293883-001	1207, 10; 1624, 25, 26, 35, 36, 40, 50, 55
Speaker, Left and Right (prem)		298496-001	1611, 21, 22, 30, 81
Speakers, w/ Enclosure and Cable		330960-001	1230
Speakers, w/ Enclosure	50M101Z12-S0	159494-001	1600
Speakers, w/ Enclosure and Cable		352889-001	1234, 35, 36, 37, 38, 40, 42, 50, 52, 55, 60, 66, 67; 1660, 70
Speakers, w/ Enclosure and Cable		148108-001	1246, 47, 1272, 73, 74, 75, 77, 78; 1683, 85

Modem Cables	Spare Part
APD	137256-001
APD (1660)	304398-371
Australia (1660)	304398-011
Brazil	137256-001
Canada	137256-001
Hong Kong	137256-001
Japan	137256-001
Latin America	137256-001
PRC (1660)	304398-AA1
Switzerland	304398-111
Taiwan	137256-001
United Kingdom	165224-031
US	137256-001

Presario 1200/1600

Modem Cable/Adapters	Cable Spare Part
APD	304398-371
APD (1660, 83, 85)	137256-001
Australia	304398-011
Belgium	304398-181
France	304398-051
Germany	304398-041
Netherlands	304398-331
New Zealand	304398-011
Sweden	304398-101
United Kingdom	304398-031

Video	Assembly	Spare Part	System
Display Assy, 11.3" DSTN		293781-001	1207
Display Panel, 12.1" DSTN		158795-001	1277, 78, 79
Display Assy, 12.1" HC		332209-001	1220 (BVL4)
Display Assy, 12.1" HC		332209-001	1611
Display Assy, 12.1" HPA		203735-001	1220 (BVL2), 1215
Display Assy, 12.1" HPA		298495-001	1621, 22
Display Assy, 12.1" HPA		331013-001	1624, 25, 26
Display Assy, 12.1" HPA		330939-001	1230, 34, 35, 38, 40
Display Assy, 12.1" HPA		142648-001	1272, 73, 74, 75
Display Assy, 12.1" STN		282832-001	1610, 15, 20
Display Assy, 12.1" STN-Lite		293881-001	1210
Display Assy, 12.1" TFT		332224-001	1681
Display Assy, 12.1" TFT		352890-001	1235, 36, 37, 40, 42, 50, 52, 60, 66, 67
Display Assy, 12.1" TFT w/o Mic		331014-001	1635, 36, 40, 50
Display Assy, 12.1" TFT/LVDS		387544-001	1670
Display Panel, 12.1" HPA II		102248-001	1255
Display Panel, 12.1" TFT		173540-001	
Display Panel, 12.1" TFT/LVDS		142304-001	1683, 85, 87
Display Panel, 12.1" TFT/LVDS	50M101Z22-S0	170091-001	1600
Display Panel, 12.1" TFT/LVDS		159038-001	1246, 77, 78, 79
Display Panel, 13.0" DSTN		158796-001	1246, 78, 79
Display Assy, 13.0" HPA		142649-001	1275
Display Panel, 13.3"		387545-001	1660
Display Assy, 13.3" TFT		331012-001	1655
Display Panel, 13.3" TFT/LVDS		142305-001	1688
Display Panel, 14.1" TFT/LVDS		142306-001	1690
Display Panel, 14.1" TFT/LVDS	50M101Z04-S0	159486-001	1600
Display, Status w/ Cables		293737-001	All

ROM Information	Spare Part	System
ROMPaq	261922-001	All

Presario 1200/1600

Power Supply/Battery	Assembly	Spare Part	System
Battery Pack, E.D. NiMH		330935-001	1230, 34, 35, 40; 1636
Battery Pack, E.D. NiMH		388648-001	1246, 55, 72, 73, 74, 75, 77, 78, 79
Battery, Li-Ion		292560-001	All
Battery, Li-Ion		330936-001	1234, 35, 36, 37, 38, 40, 42, 50, 52; 1624, 25, 26, 35, 40
Battery, Li-Ion		388647-001	1255, 60, 66, 67, 75; 1660, 70, 83, 85, 87, 88, 90
Battery Pack, Li-Ion, Enhanced	50M101X13-S0	138184-001	1600
Battery Pack, Li-Ion, Enhanced		388647-001	1246, 47, 77, 78, 79
Battery, NiMH		293861-001	All
Clock/Battery		117099-001	All


Presario 1200/1600

Presario 1207, 1210, 1215, 1220, 1220ES, 1230

Presario 1610, 1611, 1615, 1620, 1621, 1622, 1630, 1681

Memory Upgrade Chart

MAXIMUM MEMORY IS 96 MB



ADD ANY ONE OF THE FOLLOWING
MEMORY MODULES:

16-MB MEMORY MODULE, SODIMM - OPTION PN 293820-001

32-MB MEMORY MODULE, SODIMM - OPTION PN 293821-001


64-MB MEMORY MODULE, SODIMM - OPTION PN 293822-001

Presario 1200/1600

Presario 1234, 35, 36, 37, 38, 40, 42, 50, 52

Presario 1624, 25, 26, 35, 36, 40, 50, 55

Memory Upgrade Chart



MAXIMUM MEMORY IS 96 MB

ADD ANY ONE OF THE FOLLOWING
MEMORY MODULES:

16-MB MEMORY MODULE - OPTION PN 293820-001


32-MB MEMORY MODULE - OPTION PN 293821-001

64-MB MEMORY MODULE - OPTION PN 293822-001

Presario 1200/1600

Presario 1255, 60

Memory Upgrade Chart



ADD ANY ONE OF THE FOLLOWING MEMORY BOARDS

32-MB SDRAM OPTION PN 293821-002


64-MB SDRAM OPTION PN 293822-002

128-MB SDRAM OPTION PN 401040-B21

Presario 1200/1600

Presario 1660, 1670

Memory Upgrade Chart



ADD ANY ONE OF THE FOLLOWING MEMORY BOARDS

32-MB SDRAM OPTION PN 293821-002

64-MB SDRAM OPTION PN 293822-002

128-MB SDRAM OPTION PN 401040-B21