

Presario 16XL

System Boards	Spare Part	Model
System Board, I/O w/ 64 MB SDRAM	159483-001	1600T; 16XL, 16XL 140, 141, 142, 143, 144, 145, 146, 147, 150
System Board, I/O w/ 64 MB SDRAM 1.5V	201805-001	16XL255, 257

Configuration Code	System Board Spare Part	Model
CLSF	144018-001	1690XL
DCHZ	159483-001	1600T; 16XL1
DCJ1	159483-001	16XL147
DCJ2	159483-001	16XL143
DCJ3	159483-001	16XL141
DCJ4	159483-001	16XL145
DCJ5	159483-001	16XL146
DCJ6	159483-001	16XL142
DCJ7	159483-001	16XL145
DCJ8	159483-001	16XL144
DCJ9	159483-001	16XL140
DCJB	159483-001	16XL146
DCJC	159483-001	16XL150
FHQ3	201805-001	16XL255
FHQ5	201805-001	16XL257

Microprocessors	Spare Part	System
466 MHz, 128K Cache	174040-001	1600T; 16XL, 16XL140, 141, 144, 146, 147, 150
500 MHz, 128K Cache, 2V	159484-001	1600T; 16XL, 16XL141, 142, 143, 144, 145, 146, 150
533 MHz, 128K Cache, 2V	187724-001	16XL150
566 MHz, Celeron, 1.5V FC-PGA	201565-001	16XL255, 257
PIII/500 MHz, 256K Cache	174041-001	1600T; 16XL, 16XL142, 145, 146, 147
PIII/600 MHz, 256K Cache	159485-001	1600T, 16XL257
PIII/650 MHz, 256K Cache	175308-001	1600T, 16XL256

Memory Modules/Boards	Spare Part	System
32 MB, PC100	122699-001	1600T
64MB, PC100	122700-001	1600T
128 MB	123930-001	1600T

Hard Drives	Spare Part	System
6.0 GB	170087-001	1600T; 16XL140, 141, 142, 144, 145, 146, 150, 255, 256
12.0 GB	170086-001	1600T; 16XL143, 146, 147, 257, 258
18.0 GB	161544-001	1600T

Diskette Drives	Spare Part	System
1.44 MB	159496-001	1600T; 16XL140, 141, 142, 143, 144, 145, 146, 147, 150, 255, 256, 257, 258

Presario 16XL

CD-ROM	Spare Part	System
24X CD-ROM, 1000	159487-001	1600T; 16XL140, 142, 145
DVD, 6X, 3C	159488-001	1600T; 16XL141, 142, 143, 144, 145, 146, 147, 150
DVD, 8X	201806-001	16XL 255, 256, 257, 258
RW 1000	170085-001	1600T; 16XL142, 145

Cables	Spare Part	System
Misc. Cable Kit	159497-001	1600T; 16XL140, 141, 142, 143, 144, 145, 146, 147, 150, 255, 256, 257, 258

Miscellaneous Internal	Spare Part	System
Fan	159500-001	1600T; 16XL140, 141, 142, 143, 144, 145, 146, 147, 150, 255, 256, 257, 258
Heat Spreader FCPGA, 1000	174042-001	1600T; 16XL142, 145, 146, 147, 255, 256, 257, 258
Heat Spreader, 1000	159501-001	1600T; 16XL140, 141, 142, 143, 144, 145, 146, 150
LCD w/ Internet Switch	159495-001	16XL140, 141, 142, 143, 144, 145, 146, 147, 150, 255, 256, 257, 258
Voltage Converter Board, 3C	352891-001	1600T; 16XL140, 141, 142, 143, 144, 145, 146, 147, 150, 255, 256, 257, 258

Miscellaneous External	Spare Part	System
AC Adapter	298239-001	1600T; 16XL142, 143, 145, 146
AC Adapter, APD	164854-001	16XL140, 141, 144, 146, 147, 150
Adapter, 60W Slim-2 Wire	180676-001	1600T; 16XL142, 143, 145, 146, 257, 258
Adapter, 60W Slim-3 Wire	180675-001	16XL140, 141, 144, 146, 147, 150, 255, 256
Base Enclosure	159491-001	16XL140, 141, 142, 144, 145, 146, 147, 150
Base Enclosure	159491-002	1600T; 16XL255, 256, 257, 258
Button Board Cover, 1000	159493-001	1600T; 16XL140, 141, 142, 143, 144, 145, 146, 147, 150, 255, 256, 257, 258
CPU Cover, Upper, 1000	159492-001	1600T; 16XL140, 141, 142, 143, 144, 145, 146, 147, 150, 255, 256, 257, 258
Hardware Kit, Misc.	159499-001	1600T; 16XL140, 141, 142, 143, 144, 145, 146, 147, 150, 255, 256, 257, 258
Keyboard	170090-001	1600T; 16XL140, 142, 145, 147
Keyboard, BEL	170090-381	16XL141, 144, 146, 150, 256
Keyboard, DK	170090-081	16XL141, 144, 146, 150, 256
Keyboard, FR	170090-051	16XL141, 144, 146, 150, 256
Keyboard, GR	170090-041	16XL144, 256
Keyboard, IT	170090-061	16XL141, 144, 146, 150, 256
Keyboard, JP	170090-291	16XL143, 146, 257, 258
Keyboard, LA	170090-161	16XL142, 145, 256
Keyboard, NL	170090-331	16XL141, 144, 146, 150, 256
Keyboard, NO	170090-091	16XL141, 144, 146, 150, 256
Keyboard, PT	170090-131	16XL146, 255
Keyboard, SE	170090-101	16XL141, 144, 146, 150, 256

Continued

Presario 16XL

Miscellaneous External	Spare Part	System
Keyboard, SG	170090-311	16XL141, 144, 146, 150, 256
Keyboard, UK	170090-031	16XL141, 144, 146, 150, 256
LCD Board w/ Internet Switch	159495-001	1600T; 16XL140, 141, 142, 144, 145, 146, 147, 150
LCD Indicator Module	138187-001	1600T; 16XL140, 141, 142, 143, 144, 145, 146, 147, 150, 255, 256, 257, 258
LCD Indicator Module II	177457-001	1600T; 16XL140, 141, 142, 143, 144, 145, 146, 147, 150, 255, 256, 257, 258
Modem, K-56K Mini 3 – Australia	159502-011	16XL140, 147
Modem, K-56K Mini 3 – International	159502-002	16XL140, 141, 144, 146, 147, 150, 255, 256
Modem, K-56K Mini 3 – United States	159502-001	1600T; 16XL142, 143, 145, 146, 257, 258
Palm Rest w/ Touchpad/Button Board 1000	159490-001	1600T; 16XL140, 141, 142, 143, 144, 145, 146, 147, 150, 255, 256, 257, 258
Plastic Kit, Miscellaneous	159498-001	1600T; 16XL140, 141, 142, 143, 144, 145, 146, 147, 150, 255, 256, 257, 258
Port Replicator	175310-001	1600T; 16XL140, 141, 142, 143, 144, 145, 146, 147, 150, 255, 256, 257, 258
Speakers, w/ Enclosure	159494-001	1600T; 16XL140, 141, 142, 143, 144, 145, 146, 147, 150, 255, 256, 257, 258
Video	Spare Part	System
Display Panel, 12.1" TFT/LVDS	170091-001	1600T; 16XL140, 141, 142, 144, 145, 146, 150
Display Panel, 13.3" TFT/LVDS	201075-001	16XL255
Display Panel, 14.1" TFT/LVDS	159486-001	1600T; 16XL141, 142, 143, 144, 145, 146, 147, 150
Display Panel, 14.1" TFT/LVDS	201074-001	16XL256, 257, 258
Power Supply/Battery	Spare Part	System
Battery Pack, Li-Ion, Enhanced	138184-001	1600T; 16XL140, 141, 142, 143, 144, 145, 146, 147, 150, 255, 256, 257, 258

Presario 16XL

Memory Upgrade Chart

Information not available at time of print

For latest updates see [Http://www.Compaq.Com/Support/Techpubs/Org.
TechPaq, and QuickFind](http://www.Compaq.Com/Support/Techpubs/Org.TechPaq, and QuickFind)