

Presario 1800

Processor/System Boards	Spare Part	System
Processor Board w/o Processor	331009-001	1805
Processor Board w/o Processor	347731-001	1810
System I/O Board	138172-001	1825, 27, 30
System I/O Board w/ 64 MB SDRAM	158804-001	1827, 30

Configuration Code	System Board Spare Part	Model
BY92	331009-001	1805
BY93	331009-001	1805
BY95	331009-001	1805
BZB2	347731-001	1810
BZB3	347731-001	1810
CLV5	138172-001	1825
CTV3	158804-001	1830
CTV4	158804-001	1827
CTV5	158804-001	1830
CTV6	158804-001	1830

Microprocessors	Spare Part	System
PII/266	330983-001	1805
PII/300	347733-001	1810
PII/366 w/ 256K Cache	138173-001	1825, 30
PII/400 w/ 256K Cache	138174-001	1825
PIII/450 w/ 256K Cache	158805-001	1827, 30

Memory Modules/Boards	Spare Part	System
16 MB System Memory, SODIMM	293726-001	1805, 10
32 MB System Memory, SODIMM	293727-001	1805, 10
64 MB System Memory, SODIMM	332208-001	1805, 10
64 MB System Memory, SODIMM, PC100	122700-001	1825, 27, 30
128 MB System Memory, SODIMM, PC100	123930-001	1827, 30

Hard Drives	Spare Part	System
3.2 GB	330968-001	1805
4.0 GB	330969-001	1805, 10
4.0 GB, IDE	143923-001	1825
6.0 GB	347548-001	1805, 10
6.4 GB, IDE	138179-001	1825, 27, 30
10.0 GB, IDE	143924-001	1825

Diskette Drives	Spare Part	System
1.44 MB	331165-001	1805, 10
1.44 MB	138188-001	1825, 27, 30
120 MB	143927-001	1825

CD-ROM Drives	Spare Part	System
DVD	347549-001	1810
DVD, 4X, 2C	138178-001	1825, 30

Continued

Presario 1800

CD-ROM Drives	Spare Part	System
DVD, 6X	158165-001	1827, 30
24X CD-ROM	330967-001	1805
24X CD-ROM, 2C	143922-001	1825

Cables	Spare Part	System
Miscellaneous Cable Kit	331167-001	1805, 10
Miscellaneous Cable Kit	138189-001	1825, 27, 30

Miscellaneous Internal	Spare Part	System
Audio Board w/ Jacks	331010-001	1805, 10
LCD Interface Board TFT	293156-001	1805, 10
LCD Indicator Module	138187-001	1827, 30
LCD Interface Board TFT, 13.3"	347558-001	1805, 10
LCD Internet Switch Board	138186-001	1827, 30
Voltage Converter Board	331019-001	1805, 10
Voltage Converter Board	138177-001	1825, 27, 30
Fan	332228-001	1805, 10
Fan	138162-001	1825, 27, 30
Heat Spreader	138163-001	1830
Heat Spreader II	159698-001	1827, 30
Ethernet, LAN Card, PCI	138164-001	1825

Miscellaneous External	Spare Part	System
AC Adapter	298239-001	1805, 10, 25, 27, 30
Enclosure, Base	138182-001	1830
Enclosure, Base LS120	143925-001	1830
Hardware Kit, Misc.	138160-001	1825, 27, 30
Hardware, Plastic Kit, Misc.	293761-001	1805, 10
Keyboard	138180-xx3	1830
Keyboard, US	330981-001	1805, 10
Keyboard, US	138180-001	1825, 27, 30
Palm Rest	332226-001	1805, 10
Palm Rest w/ Touch Pad and Button Board	138181-001	1825, 27, 30
Plastics Kit, Misc.	138190-001	1825, 27, 30
Port Replicator	138167-001	1830
Speaker w/ Enclosure and Cable	138185-001	1825, 27, 30
Speakers	293883-001	1805, 10

Modems	Assembly	Spare Part	System
Modem, 56K Data/Fax w/o DRAM		138610-001	1805, 10
Modem, 56K Data/Fax w/o SRAM	292306-001	138659-001	1805, 10
Modem, 56K Data/Fax w/o SRAM		400445-001	1825, 27, 30

Modem Cables	Assembly	Cable Spare Part
APD	112666-003	137256-001
Canada	112666-003	137256-001
US	112666-003	137256-001

Presario 1800


Modem Cable/Adapters	Assembly	Spare Part
Australia	112666-003	137256-001
New Zealand	112666-003	137256-001

Video	Spare Part	System
Display Assembly, 13.3", TFT	331012-001	1805, 10
Display Assembly, 14.1", TFT	138175-001	1825, 27
Display Assembly, 15.0", TFT	138176-001	1825, 30

Power Supply/Battery	Spare Part	System
Battery, Li-Ion	330936-001	1805, 10
Clock/Battery	117099-001	1805, 10
Battery Pack, Smart Li-Ion Enhanced	138184-001	1825, 27, 30

Presario 1800

Memory Upgrade Chart



MAXIMUM MEMORY IS 96 MB

ADD ANY ONE OF THE FOLLOWING
MEMORY MODULES:

16-MB MEMORY MODULE - OPTION PN 293820-001

32-MB MEMORY MODULE - OPTION PN 293821-001

64-MB MEMORY MODULE - OPTION PN 293822-001