

Presario 7EL

System Boards	Assembly	Spare Part	System
System Board w/ 1394	187221-101	201479-001	7000T; 7EL110, 140, 147, 160, 180, 193

Configuration Code	Assembly	System Board Spare Part	Model
FDY2	187221-101	207611-001	7EL140
FDY4	187221-101	207611-001	7EL140
FDY5	187221-101	207611-001	7EL140
FDY9	187221-101	207611-001	7EL193
FDYC	187221-101	207611-001	7EL147
FDYF	187221-101	207611-001	7EL140
FDYG	187221-101	207611-001	7EL160
FDYH	187221-101	207611-001	7EL160
FDYJ	187221-101	207611-001	7EL180
FDYK	187221-101	207611-001	7EL180
FDYN	187221-001	207611-001	7EL110
FDYZ	187221-101	207611-001	7000T

Microprocessors	Assembly	Spare Part	System
Celeron 600 (128)	174029-003	196362-001	7EL100
733 MHz, PIII	158807-010	196366-001	7000T
Celeron 700, PIII	174029-006	202112-001	7EL110
Coppermine 700 (100)	158353-011	196365-001	7000T
Coppermine 800 (133), PIII	158807-011	196367-001	7000T; 7EL140, 147
Coppermine 866 (133), PIII	158807-001	191544-001	7EL160
Coppermine 933 (133), PIII	158807-012	180739-001	7000T; 7EL180, 193
1000/133MHz, PIII	158807-013	180738-001	7000T

Memory DIMMs	Assembly	Spare Part	System
64MB SDIMM, PC133	168694-001	170080-001	7000T
128 MB SDIMM, PC133	168695-001	170081-001	7000T; 7EL140, 147, 160, 180, 193

Miscellaneous	Assembly	Spare Part	System
Bottom Door Cover with CD Holders	174970-001	202399-001	7000T; 7EL110, 140, 147, 160, 180, 193
Hard Drive Brackets (Includes 2 brackets & 4 screws)		195413-001	7000T; 7EL110, 140, 147, 160, 180, 193
Keyboard Internet LED, Quartz	179355-XXX	180190-XXX	7000T; 7EL110, 140, 147, 160, 180, 193
Mouse, Scroll, Smoky Qtz		195503-001	7000T; 7EL110, 140, 147, 160, 180, 193
Power Switch w/Holder	189524-001	199354-001	7000T; 7EL110, 140, 147, 160, 180, 193
Rail, Left & Right (3.25")		199353-001	7000T; 7EL110, 140, 147, 160, 180, 193
Rail, Left & Right (5.25")		202393-001	7000T; 7EL110, 140, 147, 160, 180, 193
Top Door	174975-001	202398-001	7000T; 7EL110, 140, 147, 160, 180, 193

Presario 7EL

Controller Boards	Assembly	Spare Part	System
Audio Board, PCI ES 1373	102392-002	113897-003	7000T; 7EL110, 140, 147, 160, 180, 193
NIC 10/100, w/ WOL, Freedom II	153110-001	157045-001	7000T; 7EL140, 147, 193
Sound Blaster PCI Audio 128V	102392-003	113897-003	7000T
Sound Blaster Live Audio		153147-001	7000T; 7EL180, 190

Graphics Boards	Assembly	Spare Part	System
Graphics M64/16MB No TV	179250-002	182757-001	7000T; 7EL147, 193
Graphics M64/16MB TV Out	179250-003	182758-001	7000T; 7EL160, 180
Graphics, NV15, 32-MB, DDR		180284-001	7000T
Graphics, NV15, 64-MB, DDR		195394-001	7000T
NVID M64/32MB TV Out	179250-004	192068-001	7000T; 7EL110, 140

Hard Drives	Assembly	Spare Part	System
10.0 GB		168028-001	7000T
10.0 GB, 7200 rpm	165139-001	168029-001	7000T
15.0 GB	168097-001	170389-001	7000T; 7EL110
20.0 GB	165133-001	168031-001	7000T; 7EL140
20.0 GB, 7200 rpm		199349-101	7000T
30.0 GB	165134-001	168628-001	7EL140, 160, 180
30.0 GB, 7200 rpm	167971-001	173343-001	7000T
40.0 GB	171457-001	173342-001	7EL147
40.0 GB, 7200 rpm	166115-001	170047-001	7000T
60.0 GB, 5400 rpm	188627-001	201527-001	7EL193
ZIP 100MB		191167-001	7000T

CD-ROM Drive	Assembly	Spare Part	System
4X Combo (DVD/CD-RW)		196626-001	7000T
40X CD-Rom, Quartz	388770-FB2	161160-001	7000T
CD RW 4/4/32 Quartz	152628-HB2	191162-001	7000T; 7EL110, 140, 147, 160, 180, 193,
CD-RW 8X		190074-001	7000T
DVD, 16X, Quartz	176253-CB0	180593-001	7000T
DVD, 10X	177719-FB2	196748-001	7EL110, 140, 147, 160, 180, 193,

Diskette Drives	Assembly	Spare Part	System
1.44 MB, Quartz		191168-001	7000T; 7EL110, 140, 147, 160, 180, 193

Modems	Assembly	Spare Part	System
56Kbps PCI ITU V.90 LA Excluded (Enduro)	146139-002	166386-002	7000T; 7EL147, 193
56Kbps PCI, V.90 (Scooter)	155817-001	166358-002	7EL110, 140, 160, 180
V.90 DOMESTIC, GWG	125366-001	128384-001	7000T
V.90 CMPLNT DT/FA, Enduro	166386-001	146139-001	7000T

Presario 7EL


Cables	Assembly	Spare Part	System
Audio Cable Cord	387527-001	149806-001	7000T; 7EL110, 140, 147, 160, 180, 193
Audio Cable Cord, 18"	171891-009	174773-001	7000T; 7EL110, 140, 147, 160, 180, 193
Cable Board	163607-002	202458-001	7000T; 7EL110, 140, 147, 160, 180, 193
CD/DVD Cable	167344-002	198290-001	7000T; 7EL110, 140, 147, 160, 180, 193
Diskette Cable	238078-005	198291-001	7000T; 7EL110, 140, 147, 160, 180, 193
Hard Drive Cable	190320-001	198289-001	7000T; 7EL110, 140, 147, 160, 180, 193
USB Data Cable	163606-002	202405-001	7000T; 7EL110, 140, 147, 160, 180, 193

Power Supply/Battery	Assembly	Spare Part	System
Power Supply, 200 W		153652-001	7000T; 7EL110, 140, 147, 160, 180, 193

Presario 7EL

Memory Upgrade Chart

SYSTEM BOARD
207611-001



Maximum memory and option part numbers not available at time of print. For the latest updates, see <http://www.compaq.com/support/techpubs/grg>, QuickFind, or TechPaq.