

ProLiant ML350

Processor Boards	Spare Part	Model
Processor Board	163357-001	600 – 933 MHz
System Feature Board	216110-001	1 GHz
System I/O Board	216109-001	1 GHz

SW1 Switch Settings

SW	Function	Default Position
1	Clear Setup and Power-on Passwords	Off
2	Clear CMOS Configuration Settings	Off
3	Tower/Rack Mount	Off (tower)
4	ROMPAQ Disaster Recovery	Off (normal)

Configuration Code	Model	System Board Spare Part
CQH3	Tower, P600	163357-001
CQH4	Tower, P600	163357-001
DD51	Tower, P600	163357-001
DD52	Tower, P600	163357-001
DMY1	Tower, P733	163357-001
DMY2	Tower, P733	163357-001
DMZ1	Tower, P733	163357-001
DMZ2	Tower, P733	163357-001
FDR1	800/133, Coppermine	163357-001
FDR2	800/133, Coppermine	163357-001
FDR3	800/133, Coppermine	163357-001
FDS1	800/133, Coppermine	163357-001
FDS2	800/133, Coppermine	163357-001
FDT1	866/133, Coppermine	163357-001
FDT2	866/133, Coppermine	163357-001
FDV1	866/133, Coppermine	163357-001
FDV2	866/133, Coppermine	163357-001
FDV3	866/133, Coppermine	163357-001
FR91	933/133, Coppermine	163357-001
FR92	933/133, Coppermine	163357-001
FR93	933/133, Coppermine	163357-001
FSC1	933/133, Coppermine	163357-001
FSH1	1 GHz/133 FCPGA	216109-001
FSH2	1 GHz/133 FCPGA	216109-001
FSJ1	1 GHz/133 FCPGA	216109-001

Microprocessors	Assembly	Spare Part
600/133 MHz, PIII		166146-001
667/133 MHz, PIII		166145-001
733/133 MHz, PIII		164272-001
800/133 MHz, Coppermine	137365-011	187781-001
866/133 MHz, Coppermine	137365-006	187782-001
933/133MHz, Coppermine		196628-001
1 GHz/133 MHz, FCPGA	158807-307	216111-001

ProLiant ML350

Memory Boards/Modules	Assembly	Spare Part	Model
64 MB DIMM, 8Mx72, 133, CL3	127004-021	159225-001	600-933 MHz
128 MB DIMM, 16Mx72, 133, CL3	127007-031	164278-001	All
128 MB DIMM, SDRAM	127007-021	159226-001	All
256 MB DIMM, 2x16Mx72, 133, CL3	127005-021	159304-001	All
256 MB DIMM, 32Mx72, 133, CL3	127005-031	159377-001	All
512 MB, DIMM, 2x32Mx72,133, CL3	127006-031	159227-001	All

Miscellaneous	Assembly	Spare Part	Model
Cover Kit, Miscellaneous		216104-001	1 GHz
Drive Adapter, 3.5"	179026-001	155012-001	All
Drive Cage, LVD	329316-004	159137-001	All
Drive Cage, Non Hot-Plug	158821-001	163349-001	All
Fan, 120mm		163347-001	All
Fan, 120mm, Single Speed	298240-004	212944-001	1 GHz
Heat Sink	216994-001	221011-001	1 GHz
Hot-Plug Upgrade Kit		188595-001	All
Keyboard, Opal	296433-006	386209-001	All
Plastics Kit, Miscellaneous		163345-001	600-933 MHz
Plastics Kit, Miscellaneous		216106-001	1 GHz
Power Processor Module/Voltage Regulator Board	155681-001	157825-001	All
Power Switch w/ LED and Cable		163350-001	600-933 MHz
Power Switch w/ LED and Cable		216107-001	1 GHz
Terminator Board		158271-001	600-933 MHz
Tower-to-Rack Conversion Kit		164277-001	All
Front Bezel		164274-001	600-933 MHz
Front Bezel		216105-001	1 GHz

Hard Drives	Assembly	Spare Part	Model
9 GB, Wide-Ultra2, Hot-Plug, 80 Pin		104665-001	600-933 MHz
9 GB, Wide-Ultra2 SCSI		349534-001	600-933 MHz
9.1 GB, Wide-Ultra3 SCSI, Hot-Plug		216113-001	1 GHz
9.1 GB, Wide-Ultra3 SCSI, Non Hot-Plug		216112-001	1 GHz
Blank Tray	349448-001	122759-001	All

Diskette Drives	Assembly	Spare Part	Model
1.44 MB	388617-702	158266-001	All

CD-ROM	Assembly	Spare Part	Model
32X		163354-001	600-933 MHz
40X, Opal	388770-106	179963-001	933-1GHz

ProLiant ML350


Cables	Assembly	Spare Part	Model
Cable Kit, Miscellaneous Signal	271947-003	163353-001	All
Cable, SCSI I/E, All		188596-001	All
Cable, SCSI LVD, 30"	166298-013	163351-001	All
Cable, Ultra3, 4 Dev, LVD	148785-001	174599-001	All

Battery/Power Supply	Assembly	Spare Part	Model
Battery, 3V, Lithium	298031-001	234556-001	All
Power Supply, 300W		163346-001	600-933 MHz
Power Supply, 300W		216108-001	1 GHz


ProLiant ML350

Memory Upgrade Chart

SYSTEM BOARD
163357-001, 216109-001



A MAXIMUM OF 2 GB TOTAL MEMORY



64-MB 133 MHz SDRAM DIMMs	OPTION PN 128276-B21
128-MB 133 MHz SDRAM DIMMs	OPTION PN 128277-B21
256-MB 133 MHz SDRAM DIMMs	OPTION PN 128278-B21
512-MB 133 MHz SDRAM DIMMs	OPTION PN 128279-B21