

TaskSmart N-Series

System Boards	Assembly	Spare Part
System I/O Board, w/o Processor	010156-104	188240-001

Configuration Code	System Board Spare Part
FQD1/N2400	188240-001

Microprocessors	Digital Classic Part	Spare Part
733/133, w/ Heat Sink	FD-61019-01	166108-001

Memory Boards/Modules	Assembly	Spare Part
256 MB, SDRAM, 64	127005-021	159304-001

Controller Boards	Assembly	Spare Part
4 CH, U-Array, External	400502-001	401859-001
NIC, Dual 10/100 TX I-B, Upgrade	010556-001	161106-001
NIC, PCI64, Dual 10/100 I-B	010555-001	161105-001

Miscellaneous	Assembly	Digital Classic Part	Spare Part
Backplane, 64/32, PCI 4 Slot	010159-001	FD-61007-01	159128-001
Board, Power Supply, Hot-Plug	007829-002	FD-86584-01	333112-001
Board, Remote Insight, PCI	165121-001		158731-001
Board, ROC RAID, 16 MB	010284-001		158855-001
Board, Simplex, SCSI, LVD, CPR	010060-001	FD-79844-01	387090-001
Board, Voltage Regulator	155681-001	FD-60992-01	157825-001
Board, Voltage Regulator	330638-001		329267-001
Drive Cage			159137-001
Hardware Kit, Misc.		FD-61028-01	159542-001
Fan, 92mm, 62 CFM	327412-003		173907-001
Fan, 92mm, Power Supply	157383-001	FD-61024-01	159203-001
Plastic Kit, Misc.		FD-61029-01	327319-001
Plate Kit, Misc.			188245-001
Power Switch, w/ Cable and LED	333347-005	FD-61011-01	144086-001

Hard Drives	Assembly	Digital Classic Part	Spare Part
18 GB, U3, 10K, 80 Pin	142673-B22		152190-001
Blank Tray	349448-001	FD-60614-01	122759-001

CD-ROM Drives	Assembly	Spare Part
24X, 50 Pin, Opal	341011-001	323332-001

Diskette Drives	Assembly	Spare Part
1.44S-BTN, Opal	141087-705	179161-001

TaskSmart N-Series

Cables	Assembly	Digital Classic Part	Spare Part
Cable Kit, Misc. Power		FD-61030-01	327919-001
Cable Kit, Misc. Signal		FD-61027-01	159129-001
Cable, VPB, Keyboard/Mouse	158397-001		166655-001

Battery/Power Supply	Assembly	Digital Classic Part	Spare Part
275 W, Hot-Plug	108859-001	FD-61004-01	159125-001
Battery, 3V, Lithium	334149-001		179322-001